


6\*9cm

## 温湿度计用户手册

## 一、产品图解



## 二、操作方法



1. 关机状态下，短按开机；
2. 开机状态下，短按切换温度单位以℃（摄氏度）  
°F（华氏度）显示；
3. 开机状态下，长按3秒关机。

## 三、产品规格

温度测量范围：-50℃~+70℃（-58°F~+158°F）  
 温度测量精度：±1℃（1.8°F）  
 温度分辨率：0.1℃（0.2°F）  
 湿度测量范围：10%RH~99%RH  
 湿度测量精度：±5%RH 湿度分辨率：1%  
 使用电池：CR2032\*1

## 四、基本功能

开关机功能  
 单位转换  
 温度显示  
 湿度显示  
 舒适度标识

## 五、舒适度标识说明

湿度显示10%~39%之间，屏幕显示☺；  
 湿度显示40%~70%之间，屏幕显示☺☺；  
 湿度显示71%~99%之间，屏幕显示☺☺☺。

6\*9cm

## User manual of Thermo-hygrometer

## ◆Product diagram



## ◆Operation Method



1. In the power-off state, short press the key to turn on;
2. In the power-on state, short press the key to switch the temperature unit to °C (Celsius) °F (Fahrenheit);
3. In the power-on state, press and hold the key for 3 seconds to power off.

## ◆Product specifications

Temperature measurement range: -50℃~+70℃（-58°F~+158°F）  
 Temperature measurement accuracy: ±1℃（1.8°F）  
 Temperature resolution: 0.1℃（0.2°F）  
 Humidity measurement range: 10%RH~99%RH  
 Humidity measurement accuracy: ±5%RH  
 Humidity resolution: 1%  
 Power supply: CR2032\*1

## ◆Basic functions

Power on/off function  
 °C/°F switch display  
 temperature display  
 Humidity display  
 Comfort indicator

## ◆Description of comfort level

Humidity display between 10%~39% : ☺;  
 Humidity display between 40%~70% : ☺☺;  
 Humidity display between 71%~99% : ☺☺☺.